



This feature allows the communication paths available to be tested to ensure they are signalling correctly. During the test sounders will be disabled but signalling to ARC's or other devices will occur allowing a system to be checked even in an occupied building. During the test ONLY the devices selected will cause an alarm activation.

1. Enter Engineer mode and select option 9 Engineer Utilities and press 'YES'
2. Scroll up (TWICE) to the option 'Signalling Test' and press 'YES'.
3. Select the Area(s) you wish to test using keys 1-8 then press 'YES'.
4. Next Select Zone(s) you wish to test by scrolling down and selecting each Zone you wish to use by pressing the CHIME button. (A * symbol will indicate on the Zone(s) selected).
5. Press 'YES' and system will show: Log off Engineer and Arm System.
6. Press 'NO' to Arm the System as an Engineer – (This will enable the Engineer to disarm the system with the Engineer Code).
7. Activate each of the Zone(s) selected above.
8. Disarm the system with Engineer Code and then check that the signals have been sent correctly.